

Website: www.strong.com.au - E-mail:sales@strong.com.au 60 Wedgewood Road, Hallam, Victoria 3803, Australia Tel: +61 3 8795 7990 - Fax: +61 3 8795 7991

*

STRONG

How to access new feaures for SRT 5492/5495

1. Adjusting Lead In/ Out times for EPG Recordings

You can now set lead in and lead out times for timers set via the EPG or manually. Onced this features is set it will automatically work for all recordings.

Press the Menu button (1), then using Channel Down button (2) scroll down to System Settings,

then scroll across with Vol > button (3) to select Time Settings. Press OK (4)

then Vol> (3) to set time; 5, 10 or 15 minutes. Press Exit (5) and then select 'Yes' to save changes.

2. Setting Active & Passive Standby You can now set the standby mode to either Power Saving or Normal if you want the antenna signal to be passed to your TV while the unit is switched off. Press the Menu button (1), then using Channel Down button (2) scroll down to System Settings, then scroll across with Vol > button (3) to select "Front Display Settings", select either 'Normal' or 'Power Saving', then press OK (4).

3. Rotate Jpegs

You can now rotate JPEG images you are viewing via your *STRONG DVR*. Simply press the Blue Button (6) on the remote control to rotate the image to be displayed in the correct aspect. To View JPEGS Press the Menu button (1), then using Channel Down button (2) scroll down to System Settings, then scroll across with Vol > button (3) JEPG.

4 . Auto Timeshift/Timeshift Record Time

Time Shift can now be elected to be permanately on or activated by pressing Pause Button (7) during live viewing. Press the Menu button (1), then using Channel Down button (2) scroll down to Storage, then scroll across with Vol > button (3) to Disk Manager and then scroll down Vol> (3) Change to Time Shift 'On'. The Timeshift duration or time can also be adjusted via Disk Manager between 10, 30, 60, 90 & 120 Minutes. Please note that the Time SHift will restart when channel is changed.

5. Adjustable Skip Time

You can now adjust the amount of time you skip through a recorded program when you use the Page Up (8) and Page Down (9) buttons.

Press the Menu button (1), then using Channel Down button (2) scroll down to Storage, then scroll across with Vol > button (3) to Disk Manager and then scroll down Vol> (3) Skip Times. Then select either 5, 10 and 30 seconds or 1,2,2,5,10,20 or 30 minutes.



Website: www.strong.com.au - E-mail:sales@strong.com.au 60 Wedgewood Road, Hallam, Victoria 3803, Australia Tel: +61 3 8795 7990 - Fax: +61 3 8795 7991

6. PIP (Picture in Picture) Where available - not available in Composite Mode SRT 5492 & SRT 5495 now offer PIP. Picture in Picture allows you to watch one program in fullscreen mode and another channel in a small window in the top right hand corner of the screen. To Activate PIP, press the Advance Button (8). A sub Channel List will appear, simply select the channel you wish to view in the PIP Window by pressing OK Button (4). To select a different channel for the PIP Window, press the Blue Button (6), this will display the Sub Channel List and you can

then select a new channel by pressing OK (4). To swap programs in the main screen and the PIP screen press the Recall Button (9). To decrease the size of the PIP windoes press the Advance button (8). To stop the PIP feature

press the Advance Button(8) a second time.

7. File Descriptions in File Manager Menu

Files that have been recorded by the unit are accessible in both File List section and the File Manager section, Press Menu (1), then scroll down to Storage and Select option. In the Records Folder the files are labelled in a clearer format. eg; a program that was recorded on the 30th March 2010 at 11:00am on ONE HD will be displayed as

- (ONE HD) @ 110000_30MAR2010

8. File Cut Feature

You are now able to cut sections out of recorded programs. While Playing back a recorded program oress the Info button (10) twice. This will bring up a menu at the bottom of the screen. The Blue Button (6) refers to the File Edit function. Pressing the Blue Button (6) will place the unit into File Edit Mode. Pressing the OK button (4) will input the start position of the file to be cut of copied. A Small window will be displayed in the top left hand corner showing the time and frame of when the cut started. You can now skip(12) or fast forward (11) to the desired position you wish to cut or copy to. Press OK (4) button to mark the end of the section to be cut or copied. You will then be asked whether you wish to 'Cut' or 'Copy'. By Selecting 'Cut' the selected Portion will be deleted. Selecting 'Copy' allows you to create this portion into a seperate file in the File List. This file will be listed by the same name as the original but will have 'E' and a digita in front of the name (e.g. E2-ONE HD).

